



No Mix LV in Aerosols

For a 12 or 14 oz aerosol of No Mix LV:

Mix a 1/4 pint of ready to spray basecoat @ 2:1.

