



Transtar Products & Waterborne Basecoats

After testing with every available waterborne basecoat with Transtar products, these are our recommendations for use:

1. Suitable substrates for all waterborne basecoats:
All 2K primers except 6541-G, all 1K and 2K sealers and texcoats 4303 and 4313.
2. Do not put waterborne basecoats directly over:
1033, 1163, 1183, 4603, 4613, 4623, 4633, 6001, 6011, 6021, 6051, 6071 or 6541-G. If you're using one of these products, use a 1K or 2K sealer first.
3. For California, VOC compliant sealers (2.8#/gal or less) are:
6561, 7341, 7344, 7364 or 7374 primers reduced with 6700-F Series Zero VOC Reducers or use 6091 1K sealer or 9531 Signature Series 2.1 Low VOC Sealer.
4. See respective tech sheets for detailed information on the above products.